

Operation Under Fault Conditions:

If a situation occurs that results in either a Secondary Ground Fault or an Over Voltage Protection shutdown, the high voltage output of this device will be deactivated. Once shutdown, the output will not restart unless the power switch is pulled to OFF, and after five seconds turned back ON again. Alternatively, the fault shutdown may be cleared by removing the power cord from the mains outlet, waiting approximately 30 seconds, and then plugging it back in.

4 -						
15	13	12	11	10	9	8
9	10	11	12	13	15	16
18	15	13	12	10	8	7
27	22	18	16	14	12	10
	9 18	9 10 18 15	9 10 11 18 15 13	9 10 11 12 18 15 13 12	9 10 11 12 13 18 15 13 12 10	9 10 11 12 13 15 18 15 13 12 10 8

226 Series 120VAC Models 800-0106/800-0108/800-0123/800-0134

INSTALLATION:

Mounting (see Figure 1):

- For Indoor Use Only
- Use (2), #8-32 machine screws, at least 5/16" longer than the thickness of the mounting surface, and (2) #8 KEPS nuts, or (2) #8 hex nuts with internal tooth lock washers.
- No Earth grounding means is required if the sign has no exposed metallic surfaces.
- If mounting to a metal surface other than a bar frame, a minimum 0.5 in. thick non-metallic spacer must be used.
- For proper grounding of a metallic sign frame, use of a #8 internal tooth lock washer is required between the #8 hex nut and bar frame on the mounting foot labeled with the Earth Ground symbol.

- CAUTION -

This device should not be mounted in spaces or near objects that may exceed an ambient temperature of 40° C (104° F).

Wiring:

- The molded plug on the power cord must be connected to a dedicated, grounded mains circuit rated for at least 15A.
- The tube load for each power supply shall not exceed the footage limits specified in Table 1.
- The power supply output leads (GTO 10) are to be connected as shown in Figure 2.

- CAUTION -

When two or more power supplies are required on a single neon sign, the output leads from one MUST NOT be wired in series or in parallel with the leads from the other(s).

